

INSTALLATION INSTRUCTIONS

Thank you for purchasing a KP BOV Block off plate! KP recommends cleaning all old gasket material and corrosion from block off plate mounting area. You want to see bare aluminum! Please make sure this is oil or solvent free, brake cleaner or carburetor cleaner works great! Apply a small bead of Permatex Ultra Grey RTV Silicone to the mating area on the intercooler (Can be found at any auto parts store). Install BOV plate, torque cap bolts to 150 in.lb. Let silicone dry for 12 hours before using. Enjoy!

Sincerely,

The KP Team

www.kawiperformance.com

(516) 236-3648